



- NOTES:
1. REFER TO SPECIFICATION FOR ACCEPTABLE MULE-HIDE FASTENERS AND PLATES.
 2. REFER TO MULE-HIDE'S EPDM SPECIFICATIONS FOR SURFACE PREPARATION PROCEDURES FOR EXISTING MEMBRANE.
 3. PRIOR TO SEAMING APPLICATION, USE WEATHERED MEMBRANE CLEANER TO PREPARE SURFACES OF TPO AND CLEANED EPDM OR HYPALON MEMBRANES.
 4. MULE-HIDE TAPE PRIMER MUST BE USED TO PREPARE MEMBRANE SURFACES PRIOR TO APPLYING CURED COVER STRIP

MULE-HIDE PRODUCTS CO., INC.

TIE-IN TO EXISTING EPDM OR HYPALON TEAR-OFF SITUATION SYSTEMS:

ALL EPDM AND TPO SYSTEMS

DETAIL NO.:
MH-JN-162A

REVISION DATE: 07/2024