



NOTES:

1. REFER TO SPECIFICATIONS FOR FLASHING MEMBRANE REQUIREMENTS.
2. BACK NAILING WOOD BLOCKING STRIPS ARE REQUIRED ON ALL SLOPES GREATER THAN 1-1/2:12.
3. WOOD NAILERS MUST BE INSTALLED WITH PROPER FASTENERS TO MEET APPLICABLE BUILDING CODES.

ROOF SLOPE	INSULATION ATTACHMENT	DISTANCE BETWEEN NAILERS
1 1/2" - 3" PER FOOT	FASTENERS OR APPROVED LOW RISE FOAM ADHESIVE	32'-0"
1 1/2" - 3" PER FOOT	ADHERED WITH HOT ASPHALT	16'-0"
3" - 6" PER FOOT	FASTENERS OR APPROVED LOW RISE FOAM ADHESIVE	16'-0"
3" - 6" PER FOOT	ADHERED WITH HOT ASPHALT	8'-0"

**MULE-HIDE
PRODUCTS CO., INC.**

**BACK NAILING
PARALLEL WITH SLOPE
SYSTEMS:
APP MODIFIED BITUMEN**

DETAIL NO.:
MHMB-UN-SE04T

REVISION DATE: MARCH 2015