



NOTES:

1. REFER TO METAL RETROFIT SPEC FOR PROPER MEMBRANE SPlicing PROCEDURES.
2. HD PURLIN FASTENERS MUST PENETRATE THE PURLIN A MINIMUM OF 1".
3. MEMBRANE SHALL BE FASTENED INTO PURLINS ADJACENT TO THE ROOF RIDGE.

**MULE-HIDE
PRODUCTS CO., INC.
2011**

**10" RUSS
RIDGE SECUREMENT DETAIL
SYSTEMS:
METAL RETROFIT
TPO MECHANICALLY ATTACHED**

**DETAIL NO.:
MMRT-180**