



- NOTE:
1. IT IS NOT NECESSARY TO FASTEN MEMBRANE AT END LAPS.
 2. END LAPS CAN BE OVERLAPPED UP TO 1" PRIOR TO CURED COVER TAPE INSTALLATION.

**MULE-HIDE
PRODUCTS CO., INC.**

SELF-ADHERED EPDM END LAPS

**SYSTEMS:
SELF-ADHERING EPDM
SYSTEMS ONLY**

DETAIL NO.:

MHE-SA-118A

REVISION DATE: 09/2019