



NOTES:

1. FASTENERS MUST PENETRATE INTO WOOD OR METAL STUDS, WHERE WALL IS BUILT WITH STUDS.
2. INDUCTION WELD CARDBOARD DISKS ARE REQUIRED UNDER INDUCTION WELDING PLATES WHEN USING NON-FACED EPS (EXPANDED POLYSTYRENE) OR XPS (EXTRUDED POLYSTYRENE) INSULATIONS.
3. INSULATION FASTENING NOT SHOWN FOR CLARITY.

**MULE-HIDE  
PRODUCTS**

**INDUCTION WELDING PLATES  
WALL ATTACHMENT**

**SYSTEMS:  
HEAT WELD MEMBRANE  
MECHANICALLY ATTACHED**

**DETAIL NO.:**

**MHT-IWP5**

REVISION DATE: 05/2020