





## NOTES:

- 1. BEGIN INSTALLATION OF 2.4" SEAM PLATES 6" TO 9" FROM THE CORNER.
- 2. POSITION 2.4" SEAM PLATES ½" TO 1" FROM EDGE OF TPO REINFORCED MEMBRANE.
- 3. APPROXIMATELY 1/8" DIAMETER BEAD OF CUT-EDGE SEALANT IS REQUIRED ON CUT EDGES OF TPO REINFORCED MEMBRANE.

MULE-HIDE PRODUCTS CO., INC.

**INSIDE CORNER** 

SYSTEMS:

**ALL TPO SYSTEMS** 

**DETAIL NO.:** 

MHT-UN-640A

REVISION DATE: 10

10/2013