



NOTES:

1. REFER TO SPECIFICATIONS FOR FLASHING MEMBRANE REQUIREMENTS.
2. WOOD NAILERS MUST BE INSTALLED WITH PROPER FASTENERS TO MEET APPLICABLE BUILDING CODES.
3. LAPS IN FLASHING MUST BE OFFSET FROM LAPS IN FIELD SHEET.
4. CAP SHEET MUST BE HEATED AND GRANULES EMBEDDED IN SURFACE AT ALL LAPS OVER GRANULATED SURFACES WHEN INSTALLING THE CAP SHEET.
5. INSTALL HVAC UNITS AFTER THE ROOF MEMBRANE AND FLASHINGS HAVE BEEN INSTALLED, IF POSSIBLE.

**MULE-HIDE
PRODUCTS CO., INC.**

**HVAC CURB
WOOD
SYSTEMS:**

APP MODIFIED BITUMEN

DETAIL NO.:

MHMB-UN-CW07T

REVISION DATE: MARCH 2015