



NOTES:

1. REMOVE ALL LEAD AND OTHER FLASHING BEFORE INSTALLING FIELD FABRICATED PIPE FLASHING.
2. UNCURED FLASHING TAPE WRAPPED AROUND THE PIPE SHALL HAVE 3" (8 cm) MINIMUM MEMBRANE SEAM.
3. TEMPERATURE OF METAL COLLAR MUST NOT EXCEED 180° F (82° C).
4. USE 9 INCH WIDE UNCURED FLASHING TAPE CUT IN HALF TO FORM THE FIRST WRAP AROUND PIPE. THE SECOND WRAP SHALL BE FORMED USING A FULL WIDTH OF 9 INCH WIDE UNCURED FLASHING TAPE.

**MULE-HIDE  
PRODUCTS CO., INC.  
2005**

Field Fabricated Hot Stack

SYSTEMS:  
Fully Adhered 90mil System

DETAIL NO.:  
**MHE-511**