



NOTES:

1. REMOVE ALL LEAD AND OTHER FLASHING BEFORE INSTALLING FIELD FABRICATED PIPE SEAL.
2. ON MECHANICALLY ATTACHED SYSTEMS, INSTALL 3 FASTENERS AND PLATES AROUND PIPE EQUALLY SPACED. FASTENERS MAY ALSO BE POSITIONED MAXIMUM 12" FROM PIPE, FASTENED 12" O.C. AND FLASHED WITH WHITE MATE-LINE TAPE.
3. FASTENERS AND SEAM PLATES ARE NOT REQUIRED ON ADHERED SYSTEMS UNLESS PROJECTION DIAMETER EXCEEDS 18".
4. MUST USE EPDM TAPE PRIMER OR LOW VOC PRIMER TO INSTALL WHITE EPDM PIPE BOOT.
5. TEMPERATURE OF PIPE NOT TO EXCEED 160° F
6. DO NOT CUT PIPE BOOTS TO PULL AROUND PROJECTION. PRE-MOLDED PIPE BOOTS MUST BE SLIPPED OVER THE PIPE.
7. PRE-MOLDED PIPE BOOTS ARE NOT TO BE USED AS PITCH PANS.

**MULE-HIDE
PRODUCTS CO., INC.**

**PRE-MOLDED PIPE BOOT
WHITE EPDM
SYSTEMS:
ALL TPO SYSTEMS**

DETAIL NO.:
MHT-UN-520A

REVISION DATE: 06/2017