



NOTES:

1. PITCH PAN MUST BE FASTENED TO SUBSTRATE WITH 1 FASTENER IN EACH CORNER PIECE. PLACE FASTENER IN HOLE FOUND ON INSIDE FLANGE.
2. ShapeShift PITCH PANS CAN BE CONFIGURED INTO THE SHAPE NEEDED BY USING ANY COMBINATION OF CORNER AND STRAIGHT PIECES.
3. VERTICAL PITCH PANS CAN ONLY BE FILLED WITH JTS-1 SEALANT BECAUSE IT DOES NOT SHRINK OR SAG. NO OTHER SEALANTS ARE APPROVED.

**MULE-HIDE
PRODUCTS CO., INC.**

**ShapeShift
VERTICAL SEALANT POCKET
SYSTEMS:**

ALL EPDM SYSTEMS

DETAIL NO.:

MHE-UN-145

REVISION DATE: 05/2018