

- 1. TAPE PRIMER MUST BE APPLIED TO ALL INSIDE SURFACES AND PENETRATIONS PRIOR TO FILLING WITH SEALANT.
- 2. FILL POCKET COMPLETELY WITH THERMOPLASTIC POURABLE SEALER UNTIL THE RIM IS COVERED WITH SEALANT, ENSURE ALL VOIDS ARE FILLED.
- 3. SEALANT POCKET TO BE MINIMUM 1" FROM PENETRATION ON ANY SIDE.
- 4. ON MECHANICALLY FASTENED SYSTEMS, INSTALL A MINIMUM OF FOUR (4) 2.4" SEAM PLATES AROUND PROJECTIONS WITH A DIMENSION UP TO 6". ADDITIONAL SEAM PLATES WILL BE REQUIRED FOR PROJECTIONS WITH DIAMETERS GREATER THAN 6" AND SHALL BE SPACED 12" ON CENTER MAX.
- 5. FASTENERS AND SEAM PLATES ARE NOT REQUIRED ON ADHERED SYSTEMS UNLESS PROJECTION DIAMETER EXCEEDS 18".
- 6. APPROXIMATELY 1/8" DIAMETER BEAD OF CUT-EDGE SEALANT IS REQUIRED ON CUT EDGES OF TPO REINFORCED MEMBRANE.
- 7. TEMPERATURE OF PENETRATION NOT TO EXCEED 160° F.
- 8. PRE-MOLDED PIPE BOOTS ARE NOT TO BE USED AS PITCH PANS.

MULE-HIDE	TPO MOLDED SEALANT POCKET	DETAIL NO.:
PRODUCTS CO., INC.	SYSTEMS:	MHT-UN-527
	ALL TPO SYSTEMS	REVISION DATE: 10/2013